



**MATERIAL THICKNESS 3mm
RADIUS TO BE 5- 6mm**

TITLE
MANWAYLIDBS00A05

NOTE:
All Purewater tanks must be fully supported on a flat, level & continuous foundation providing structural support to the tank when full to maximum operating capacity. It is essential that the user refers to the conditions of installation document prior to the installation of the tank. Under no circumstances should the tank body be used to provide support to pipework and ancillary items. The tank lid is a structural part of the tank and must be in place and fitted correctly when water is contained within the tank.

DRAWN BY C.MORRIS **DATE** 10/11/2022

CUSTOMER

ALL DIMENSIONS +/- 5mm
UNLESS OTHERWISE STATED

A4

ALL DIMENSIONS IN MM - DO NOT SCALE

4

DATE 04/06/2019 **VERSION** A **NOTES** FIRST ISSUE

TANK SPECIFICATION :

INTERNAL DIMENSIONS	xxx
EXTERNAL DIMENSIONS	xxx
NOM. CAPACITY	xxx Litres
DRY WEIGHT	xxx KG
INSULATION THICKNESS	xx
WRAS CERT. NUMBER	xx
MATERIAL	xx

SCALE:1:7 SHEET 1 OF 1

purewater storage ltd